

PRIOR TO INSTALLATION

Be sure to read the information in this manual carefully before you install the Apache pigPRO indicator

NON-PRESSURIZED LINE APPLICATION

No disassembly or internal adjustment required when mounting onto a non-pressurized line.

RESET BUTTON
SCREW
JAM NUT

LIMIT SWITCH

UPPER HOUSING

UPPER END CAP

PLUNGER ROD
EXTENSION

EXTENSION POLE

LOWER END CAP

RUBBER GASKET

LOWER HOUSING

PLUNGER

LOCK SCREW
2" NPT ADAPTER

LOAD SPRING
ADJUSTER
LID

LOAD SPRING
RESET ROD

MAIN ASSEMBLY
WITH
EXTENSION POLE

DUST SEAL

UPPER HOUSING
ASSEMBLY

Install
Height

PRESSURIZED LINE APPLICATION

On-stream installation requires portions of the pigPRO to be disassembled

RESET BUTTON
SCREW
JAM NUT

LIMIT SWITCH
UPPER HOUSING

EXTENSION POLE

LOWER HOUSING
PLUNGER

LOCK SCREW
2" NPT ADAPTER

LOAD SPRING
ADJUSTER

LID

LOAD SPRING

MAIN ASSEMBLY WITH
EXTENSION POLE

DUST SEAL

UPPER HOUSING
ASSEMBLY

APACHE HOT TAP ADAPTER
Not included

Install
Height

HOLD

HOLD