



(281) 401 8142

Keeping the industry flowing

HZ BRUSH

The HZ Brush Assembly has a spring design making it ideal for aggressive cleaning. The spring is mounted in two locations on the pig providing extra support and maintaining pressure on the pipe wall. This brush is used on steel mandrel pigs and can be ran bidirectionally. Different type brushes are available for the HZ Brush Assembly.



	PIPE SIZE	PART	PART NO.
Small	12" - 18"	Brush	60131005
	12" - 18"	Spring	60132005
	12" - 18"	Assembly	60133005
Large	20" - 42"	Brush	60131007
	20" - 42"	Spring	60132007
	20" - 42"	Assembly	60133007

* BRUSH - HZ Brush Only

* SPRING - Leaf Spring, Lifter Block & HZ Brush

* ASSEMBLY - Complete HZ Brush Assembly

Small

SIZE OF PIG BODY	NO. OF BRUSHES
12"	6
14"	6
16"	6
18"	6

Large

SIZE OF PIG BODY	NO. OF BRUSHES
20"	6
24"	7
26"	7
30"	9
36"	11
42"	14

PIG PARTS